312TX
Indoor/Outdoor Wireless Thermometer and Hygrometer

Setting up Second or Third Remote Sensor

NOTE: To setup the additional sensor, bring the monitor close to the sensor.

1. Remove the back of the sensor as shown in the main instruction manual.
2. Before inserting the batteries into the sensor, ensure the correct channel is selected (see sensor diagram in main instruction manual for location of channel switch).
3. Insert the batteries.
4. The transmission light will flash on the remote sensor indicating that the signal has been sent to the monitor. Once the monitor receives the signal, it will display the current outdoor temperature on the channel chosen.
5. To setup a third sensor, follow the steps above.

For more information on the Indoor/Outdoor Wireless Thermometer and Hygrometer please refer back to the main instruction manual that came with your unit.

Thermor
16975 Leslie Street
Newmarket, ON L3Y 9A1
www.**bios**exactly.com
TH2047_051710

312TX
Thermomètre et hygromètre sans fil intérieur/extérieur

Installation du deuxième ou du troisième capteur

NOTE : Pour installer le capteur supplémentaire, rapprochez le moniteur près du capteur.

1. Retirez le dos du capteur tel qu'illustré dans le mode d'emploi principal.
2. Avant d'insérer les piles dans le capteur, assurez-vous de sélectionner le canal adéquat (référez-vous au schéma du capteur dans le mode d'emploi principal pour l'emplacement du commutateur de canaux).
3. Insérez les piles.
4. Le voyant de transmission clignotera sur le capteur à distance pour signifier que le signal a été envoyé au moniteur. Dès que le moniteur reçoit ce signal, il affichera la température extérieure actuelle sur le canal choisi.
5. Pour installer un troisième capteur, suivez les étapes ci-dessus.

Pour plus de renseignements sur le thermomètre et hygromètre sans fil intérieur/extérieur, référez-vous au mode d'emploi principal fourni avec votre appareil.

Thermor
16975 Leslie Street
Newmarket, ON L3Y 9A1
www.**bios**exactly.com
TH2047_051710